Philips
CD lens cleaner

SBCAC300

Clean and protect your CD player

Regular cleaning of your CD player's lens ensures optimum performance of your equipment. It is important to keep a CD player optical laser lens clean and dust free. This dry brush system safely removes dust, debris and other contaminants.

Clean & protect your equipment

- Lens is dry-cleaned without the use of fluids

PHILIPS
sense and simplicity

CD lens cleaner

SBCAC300/00

Specifications

Storage Media CD, Laser disc

- Supported formats: CD-Audio, CD-ROM, Photo

Product highlights

Dry cleaning

A disc with little brushes attached to it used to clean lenses inside electronic devices.

Issue date 2009-02-12

Version: 2.0.3

12 NC: 9082 100 00043
EAN: 87 10101 63536 1

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com